

Cashmere Fiber Morphology & De-Pilling Blueprint

Why Luxury Wool Sheds: Micron Fineness, The Mechanical Friction Shear, and Manual Comb vs. Electric Shaver Physics

FIBER MICRON COUNT 14.0 - 16.5 Microns	CORE MECHANISM Cuticular Migration Friction	SAFE TOOL Dense Wire Mesh Comb	DESTRUCTIVE TOOL Electric Rotary Shaver
---	--	-----------------------------------	--

THE CASHMERE PILLING MISCONCEPTION:

Pilling is not a sign of cheap manufacturing; it is an inherent physical property of true Grade-A cashmere. Spun from the delicate underbelly down of Capra hircus goats, cashmere fibers measure an astonishingly fine 14 to 16 microns (compared to 30+ microns for coarse wool). Friction causes these short, delicate fibers to migrate to the surface and tangle into micro-bobbles.

1. Tool Mechanics: Manual Brass Comb vs. Electric Rotary Shaver

De-Pilling Tool	Physical Mechanical Action	Textile Longevity Outcome
Electric Rotary Shaver	High-speed spinning circular razor blades slice off anything protruding above the knit surface.	Catastrophic damage. Slices core yarn loops; thins fabric rapidly; creates irreversible holes after 3 uses.
Pumice Sweater Stone	Abrasive volcanic rock grips fibers through coarse surface grit.	Excessive friction pulls unbroken fibers out of the weave, accelerating future pilling and shedding.
Fine Wire Mesh Comb	Precision-engineered micro-teeth catch only loose, unanchored fiber ends while gliding over knit loops.	Optimal preservation. Removes surface fuzz without cutting structural yarns; stabilizes knit over time.

2. Cashmere Quality Hierarchy: Micron Fineness & Staple Length

Cashmere Grade	Fiber Diameter & Staple Length	Long-Term Pilling & Softness Profile
Grade A (Himalayan / Mongolian)	14.0 to 15.5 microns; staple length 34 to 36mm.	Ultra-soft cloud feel. Initial light surface pilling that stabilizes completely after 2 gentle combings.
Grade B (Standard Commercial)	16.0 to 19.0 microns; staple length 28 to 32mm.	Slightly stiffer hand. Moderate pilling in high-friction zones (underarms, purse contact).
Grade C / Recycled Blend	Over 19.5 microns; short broken fibers <25mm.	Scratchy hand. Pills aggressively and continuously; fibers shed into fuzzy lint mats.

3. The Master Cashmere Care & De-Pilling Protocol

[]	Step 1: Lay Garment Completely Flat on Hard Surface Never comb a sweater on an ironing board or bed. Spread the knit out taut across a solid wooden dining table or marble island.
[]	Step 2: Hold Comb at a 45-Degree Angle Gently sweep the fine wire cashmere comb in one continuous direction along the vertical grain of the knit. Use zero downward pressure—let the teeth do the work.
[]	Step 3: Target Friction Zones Exclusively Concentrate only where pills have naturally accumulated: underarm seams, cuffs, side torso ribs, and where shoulder bag straps rest.
[]	Step 4: Hand-Wash Cold with Baby Shampoo Submerge in tepid water (under 85 deg F) with 1 teaspoon of gentle pH-neutral baby shampoo or dedicated wool wash. Soak 15 minutes; never wring or twist.
[]	Step 5: The Salad Spinner / Towel Roll Extraction Roll the wet sweater inside a dry white towel and press firmly to extract moisture, or spin gently in a clean salad spinner to expel water without agitation.
[]	Step 6: Dry Flat on Mesh Drying Rack Shape the damp garment to its exact original dimensions on a horizontal mesh rack away from direct sunlight or heat vents to prevent shrinkage.